

HOUSE OF KOLOR

TECHNICAL DATA INFORMATION

IMPORTANT NOTE: This document includes information on UC-1 and UFC-1. These products are for sale outside the United States only.

READ ALL INSTRUCTIONS THOROUGHLY BEFORE YOU BEGIN. Our products are for use by trained professional personnel using proper production automotive spray equipment suitable for the paint to be sprayed. Proper spray booth, air system, respirator and basic spray painting ability are required.

We do not recommend painting in temperatures below 70°F.

NOT INTENDED FOR USE BY THE GENERAL PUBLIC.

For controlled results, House of Kolor recommends products be used as a "total system". We do not recommend the intermixing of various manufacturers' products. This is only asking for trouble. No professional or amateur should run the risk of a job failure. Custom painting is complicated enough without gambling on untested product compatibility.

Apply only over House of Kolor primers/sealers and/or properly prepared OEM paint.

Do not apply House of Kolor products over alkyd or synthetic enamels, uncatalyzed acrylic enamel, primers, sealers or topcoats that may be coated with lacquer. You must control every step of the preparation including the products used for a successful paint job. Any unknowns such as existing primer, old paint, etc. can become the weak link in the custom painters' chain.

IMPORTANT: The data in this manual represent typical values obtained by the methods indicated. Since application variables are a major factor in product performance, this information should serve only as a general guide. Valspar assumes no obligation or liability for use of this information. Unless Valspar agrees otherwise in writing, VALSPAR MAKES NO WARRANTIES, EXPRESS OR IMPLIED, AND DISCLAIMS ALL IMPLIED WARRANTIES INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE OR FREEDOM FROM PATENT INFRINGEMENT. VALSPAR WILL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES. Unless Valspar agrees otherwise in writing, Valspar's only obligation for any defect in this product under any warranty that Valspar provides or under any other legal theory will be to replace the defective product, or to refund its purchase price, at Valspar's option.

CAUTIONS

Read Cautions and Warnings on all product can labels!

TECHNICAL DATA

Material Safety Data sheets available upon request.

TECHNICAL ASSISTANCE

(601) 798-4229

PREPARATION

BEFORE YOU BEGIN

READ ALL INSTRUCTIONS THOROUGHLY.

We do not recommend painting in temperatures below 70°F.

GENERAL INFORMATION

Poor preparation can cause future topcoat problems. Sand the original finish well. Use our KP-2CF, or KP-21 catalyzed primers over body work and for build at deep sanded areas.

1. BODY WORK

Prepare vehicle using normal custom painting methods.

- A. Before any sanding, use KC-10 Wax & Grease remover to remove any tar, wax, or grease.
- B. Grind away paint and primer in areas requiring body work.
- C. Always be aware that your hands can transfer body oil, so keep a rag between you and the surface to be primed or painted and avoid touching the vehicle with your bare hand.
- D. Use power tools to get close when sanding filler. Then block sand. Keep the block front to rear, but crossing to prevent flat spots.
- E. Always prime with our KP-2CF, or KP-21 Primers. Allow proper cure time to prevent shrinkage.
- F. Guide coat your primer with Tempo 827 so when you block sand, your sand scratches or low spots are revealed. Final sand the primer with 320- 400 grit sandpaper.

2. PRIMERS

Many bases are susceptible to staining or bleeding from plastic fillers, putties, fiberglass resins and some primers. To prevent staining, strip bare (or to OEM primer) and prime with our KP-2CF Chromate Free Kwikure Epoxy Primer or KP-21 Low VOC Epoxy Primer. ***See tech sheets for more information on KP Primers.***

NOTE: OEM (Original Equipment Manufacturer) coatings work well as a base for your paint job.

3. FOR EXISTING FINISHES

Surface should be free of wax, grease and foreign materials. Use KC-10 Wax & Grease Remover prior to any sanding. For post-sanding, use our KC-20 to remove any sanding residue for final wash. Sand the surface with 320-400 grit wet or 240-320 grit dry with a D.A. Sander (wet is best), and apply 1-2 coats of KO-Seal II (sealer). Let dry for 1 hour before top coating.

NOTE: Do not re-coat existing paint finishes in excess of 8 mils, as paint failure can result from excessive film build.

PWP SHIMRIN® PASTELS WITH PIZAZZ

GENERAL INFORMATION

SHIMRIN® Pastels with Pizzazz (PWP) are universal base coats that may simply be cleared for a final finish, or used as a base coat for Kandys or Pearls. Due to their unique chemistry make-up, they may be top coated with either acrylic lacquer or urethane enamel. Once a system is chosen (acrylic lacquer or urethane enamel) use only products within that system. Intermixing of these two systems, after the base coat, is not recommended. For example: If SHIMRIN® Base is top coated with an acrylic lacquer Kandy, it must also be cleared with an acrylic lacquer clear.

1. PREPARATION

Read 'TECH PREP' thoroughly before you begin painting. SHIMRIN® bases are susceptible to staining or bleeding from plastic fillers, putties, fiberglass resins and some primers. To prevent staining, strip bare (or to OEM primer) and prime with our KP-2CF Kwikure Epoxy Primer, or our KP-21 Kwikure Epoxy Primer. **See tech sheet for more information on KP Primers.**

2. GROUND COAT:

- Primer (KP-2CF, KP-21)
- Sealer (KO-SEAL II)

VEHICLE MUST BE ONE EVEN COLOR BEFORE APPLICATION OF PASTELS WITH PIZAZZ. Primers and sealers are commonly used as a ground coat for SHIMRIN® Bases. We recommend using KS-10 or KS-210 White as a ground coat for Pastels with Pizzazz. When using sealer, allow flash time. **See tech sheet for information on primer application and tech sheet for information on sealers.**

NOTE: Sealer is not a cure-all for poor preparation and does not prevent discoloration or bleeding.

3. WHITE BASE COAT

SHIMRIN® (BC-26) (optional)

VEHICLE MUST BE ONE EVEN COLOR BEFORE APPLICATION OF PASTELS WITH PIZAZZ. A white base can enhance the impact of some of the Pastels with Pizzazz. It is not required, but helps with some colors. We recommend that a test panel be sprayed prior to doing a complete paint job.

Apply 2-4 medium coats of BC-26 with 50% pattern overlap. Allow flash time between coats. Maintain thorough coverage.

4. MIXING SHIMRIN® PASTELS WITH PIZAZZ (PWP)

Stir SHIMRIN® Pastels with Pizzazz well. Reduce 50% (2 parts paint to 1 part reducer). Mix well.

REDUCE ONLY WITH OUR KOSMIC REDUCERS. Use the reducer best suited to your shop temperature.

See tech sheet for more information on reducers.

NOTE: Splitting or cracking is possible when using other companies' reducers or by using a reducer that is too slow for your shop conditions. Splitting or cracking may also occur when painting too fast without allowing proper dry time or by applying the base too wet and heavy.

5. APPLYING SHIMRIN® PASTELS WITH PIZAZZ (PWP)

Strain the paint into the paint gun. Air pressure 50-60 psi at the gun. 10 psi at the nozzle of HVLP. Gun distance while spraying should be approximately 6 inches. Apply 2-3 medium coats with 50% pattern overlap. Walk long objects. Allow flash time between coats. SHIMRIN® Pastels with Pizzazz will dry dull. Allow dry time before Kandy or clear is applied (usually about 30 minutes and not longer than 12 hours). Artwork may usually be taped after 1 hour of dry time. Dry time may vary based on shop and weather conditions.

SHIMRIN® FLASH TEST - ALL SHIMRIN® BASES WILL DRY DULL AND SHOULD FEEL DRY TO THE TOUCH BEFORE THE NEXT COAT IS APPLIED. Monitor religiously for maximum merging of coats.

NOTE: 2 coats of SHIMRIN® Pastels with Pizzazz equals 1/2 to 3/4 mil, leaving a minimal edge. (Tape pulls away leaving a clean, low edge.)

PWP SHIMRIN® PASTELS WITH PIZZAZZ

(continued)

6. ARTWORK & INTERCOAT CLEAR (optional)

SHIMRIN® Pastels with Pizzazz, with their low solids, are an excellent choice for artwork paint jobs. If artwork is planned, you may tape directly onto the base or apply 1 or 2 medium coats of SG-100 Intercoat Clear (for urethane enamel topcoats) or C-1 Kustom Clear (for acrylic lacquer topcoats). The clear coat will protect the SHIMRIN® Base from tape marks. **See tech sheet for more information on SG-100 Intercoat Clear.**

NOTE: Use of SG-100 Intercoat Clear is not as critical on SHIMRIN® Pastels with Pizzazz as it is on the Designer Pearls, Metallics and Neons. However, if mistapes occur, it is easy to remove them when Intercoat Clear is used.

NOTE: SG-100 Intercoat Clear is designed to protect the base coats for artwork tape-outs and blends only. DO NOT USE SG-100 AS A BUILD-UP OR TOPCOAT CLEAR, AS IT IS NOT WEATHER RESISTANT OR DESIGNED TO EXCEED 4 COATS.

CAUTION: SHIMRIN® Base coats do not have any chemical resistance until cleared. Final wash solvents will remove base coats. Use water for cleanup.

7. KANDY COAT (optional)

SHIMRIN® Pastels with Pizzazz may be Kanded with either acrylic lacquer or urethane enamel. Remember if you Kandy with acrylic lacquer, you must also clear with acrylic lacquer. (If you Kandy with urethane enamel, you must also clear with urethane enamel). **See appropriate tech sheets for Kandy application.** Our Kandy Koncentrates may be mixed with SG-100 Intercoat Clear for base coat Kandys or for graphics. **See tech sheet for Kandy Koncentrate for more information.**

8. CLEAR COAT

ALL SHIMRIN® PASTELS WITH PIZZAZZ MUST BE CLEAR-COATED (with either urethane enamel or acrylic lacquer). Once a system is chosen, after the base coat, stay with that system. Always use House of Kolor clears. **See appropriate tech sheets for more information on clear coat application.**